



# Removing Fender Frontman 15r Back panel

Written By: Greg Sawers



## INTRODUCTION

Need to get inside the amp? Remove the back panel!

---



### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Back panel



⚠ Be sure to unplug the device before proceeding.

- Use a Phillips #0 screwdriver to remove the four 21.7mm screws holding the back panel to the frame.

## Step 2



- Once the screws are out, use a plastic opening tool or spudger to pry the top of the back panel open. There may be some resistance, but it will eventually pry loose.



## Step 3



- Once the top is separated, use your hand to remove the back panel from the unit.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 10:35:54 AM.